Remote Control Features

VOD
Direct Access to Video On Demand(VOD), where available

Replay
Replays last 15 seconds of program

Help
Learn more about a feature

PAGE
Scroll to the next or previous page of listings

Exit
Return to watching television

OK
Select a highlighted item; or while watching a program, press to display or remove the **Flip Bar** or **Mini Guide**

Guide
See program listings for the current time

Day*
See listings for the next or previous day

Numbers
Press channel numbers, then **OK/SEL** to tune to a channel

PPV
Direct Access to Pay-Per-View (PPV), where available

VCR Controls
Controls VCR, **ON DEMAND** and **Digital Video Recording** (if available)

LiveTV
Displays live television programing

FAV
Tune to your Favorite channels, once you set them up

CHAN
Change channels and access the **Flip Bar**

LAST
Return to the previous screen or channel

Info
See program information

Arrows
Use to highlight guide features, or while watching television, press to begin browsing. Note: Arrows control playback of recorded programs with **DVR**

MENU
Enter and exit the **Main Menu**

SWAP
Swap between television tuners

Note: Remote pictured may not reflect your actual remote. Basic functions should be the same.

*Amount of programming data varies by system.